

POWER KEY CHEAT SHEET

KEYBOARD SHORTCUTS

h = halt
r = repeat
c = copy
t = trim
f = find
k = scene name change keyboard
esc = cancel
enter = ok
y = yes
n = no/new
s = split
v = video
F2 = display codes
F1 = information
F11 = play
F10 = stop
F12 = pause
F9 = record
SBK = storyboard key
NK = navigation key
home key = beginning of storyboard
end key = end of storyboard
NK + h = go to Main Menu
NK + e = go to Edit Window
NK +
SBK + i = insert
SBK + r = range
SBK + insert = add
SBK + del = remove
SBK + p = replace
SBK + f = searches storyboard for
same scene
SBK + l = storyboard slider then
arrow keys move

POWER KEY CHEAT SHEET

TITLES

k = scene name
alt + p = replace in storyboard
alt + n = delete all (text, boxes, etc.)
alt + r = archive
alt + f = font
alt + k = special symbols
cltr + del = delete line/box
to find scene in scene bin:
k to open screen keyboard, enter
name, enter

naming chapters with title entrances
go to first desired chapter point in
storyboard then push:
f,
NB + t,
type title entrance then
SBK + s,
enter, enter,
NB + e,
k, type name,
SBK + p

AUDIO

NB + a = go to audio/record screen
NB + m = got to audio mix window
m = mute
cltr + m = mute and advance muting
v = volume
SBK + c = create
cltr + e = apply volume change/next
ctrl + del = delete highlighted audio